

Silver Econo Roll



Black Econo Roll



Econo Travel Bag
(26" x 4" x 4" / 35.5" x 4" x 4" / 37.5" 4" x 4")

Product Features

The Econo Roll delivers a professional looking display at an economical price. Set up and break down of the display takes seconds and conveniently stores in its included padded travel bag. banner attached to the bottom of stand by double-sided tape and to the top by clamp bar.

Display Dimension	24"W x 80"H
-------------------	-------------

Graphic Size	24" W x 80 "H
--------------	---------------

Graphic Material

Super Flat Vinyl

Graphic Finishing

5" bleed at the bottom

Construction

Sturdy aluminum construction

Weights - Dimensions

Shipping Weight	9 lbs
-----------------	-------

Shipping Dimensions	4"x 4 "x 26.5 "
---------------------	-----------------

Package Includes

Aluminum Pole

Telescopic Pole (Not Adjustable)

Econo Travel Bag

Warranty

1 Year on Stand

1 Year on Graphic

Graphic Specifications

24" W x 80 "H

* Options

LED Clamp Light
35W

Clamp Light
110V

*Optional Lumina Light



Silver (24" & 33.5" & 36")



PARTS LIST



(qty 1) Econoroll Retractable Stand



(qty 1) Clamp Bar



(qty 1) Support Pole



(qty 1) Econo Travel Bag

SET UP INSTRUCTIONS


Step 1

Twist the feet.




Step 2

Assemble telescopic pole.



Step 3

Insert telescopic pole into hole.




Step 4

Pull banner out of the base.



Step 5

Attach telescopic pole to the clamp bar.



Step 6

Complete stand.

