





Econo Travel Bag (34" x 4" x 4")

Product Features

The Econo Roll delivers a professional looking display at an economical price. Set up and break down of the display takes seconds and conveniently stores in its included padded travel bag. banner attached to the bottom of stand by double-sided tape and to the top by clamp bar.

Display Dimension	32.5"W x 80"H
Graphic Size	31.5" W x 80" H

Graphic Material

Super Flat Vinyl

Graphic Finishing

5" Bleed at the bottom

Construction

Sturdy aluminum construction

Weights - Dimensions

Shipping Weight	6 lbs
Shipping Dimensions	4"x 4 "x 36 "

Package Includes

Aluminum Pole

Support Pole W/ Hook

Econo Travel Bag

Warranty

1 Year on Stand

1 Year on Graphic

Graphic Specification

31.5" W x 80" H



Silver (24" & 33.5" & 36")

* Options

LED Clamp Light 35W



Clamp Light 110V



*Support Pole W/ Hook



PARTS LIST



(qty 1) Econoroll Retractable Stand



(qty 1) Clamp Bar



(qty 1) Support Pole




(qty 1) Econo Travel Bag

SET UP INSTRUCTIONS

Step 1Twist the feet.



Step 3 Insert telescopic pole into hole.




Step 5Attach telescopic pole to the clamp bar.





Step 2Assemble telescopic pole.



Step 4Pull banner out of the base.



Step 6Complete stand.

